

**RSB-11&14B Codes**

|                             |              |                                  |
|-----------------------------|--------------|----------------------------------|
| <b>On/Standby (toggle)</b>  | 0x 807F 1AE5 |                                  |
| <b>Volume Up</b>            | 0x 807F 03FC |                                  |
| <b>Volume Down</b>          | 0x 807F 06F9 |                                  |
| <b>Mute/Unmute (toggle)</b> | 0x 807F 01FE |                                  |
| <b>3D/Surround</b>          | 0x 807F 04FB |                                  |
|                             |              |                                  |
| <b>Source (scroll)</b>      | 0x 807F 02FD | Installer Code, not on IR remote |
| <b>Sleep/Standby</b>        | 0x 807F 1EE1 | Installer Code, not on IR remote |
|                             |              |                                  |
| <b>On/Optical*</b>          | 0x 807F 0CF3 |                                  |
| <b>On/Bluetooth*</b>        | 0x 807F 0DF2 |                                  |
| <b>On/Auxiliary*</b>        | 0x 807F 0EF1 |                                  |
| <b>On/USB*</b>              | 0x 807F 12ED | Installer Code, not on IR remote |
|                             |              |                                  |
| <b>Play/Pause (toggle)</b>  | 0x 807F 21DE |                                  |
| <b>Next Track</b>           | 0x 807F 22DD |                                  |
| <b>Prev Track</b>           | 0x 807F 23DC |                                  |
|                             |              |                                  |
| <b>EQ1-Dialog (toggle)</b>  | 0x 807F 2BD4 |                                  |
| <b>EQ2-Night (toggle)</b>   | 0x 807F 2CD3 |                                  |
|                             |              |                                  |
| <b>Bass/Sub Up</b>          | 0x 807F 07F8 |                                  |
| <b>Bass/Sub Dn</b>          | 0x 807F 0AF5 |                                  |
|                             |              |                                  |
| <b>LEDs On/Off (toggle)</b> | 0x 807F 1FE0 |                                  |
|                             |              |                                  |
| <b>On/HDMI 1*</b>           | 0x 807F 15EA |                                  |
| <b>On/HDMI 2*</b>           | 0x 807F 16E9 | Not Used on RSB-6 or RSB-8       |
| <b>On/HDMI 3*</b>           | 0x 807F 17E8 | Not Used on RSB-6 or RSB-8       |
| <b>On/HDMI 5 (ARC/TV)*</b>  | 0x 807F 19E6 |                                  |

\* System wakes up and selects the desired source; i.e. no discreet "on" command needed.